

GETZEN

Serial Number	Year Manufactured
SERIES "K"	
K101 - K12100	1964 - 1967
K12101 - K31120	1968 - 1971
K31121 - K61216	1972 - 1975
K61217 - K81565	1976 - 1979
K61218 - K113438	1980 - 1985
K113439 - K117787	1986
K117788 - K124213	1987
K124214 - K127562	1988
K127563 - K131003	1989
K131004 - K136176	1990
K136177 - K137783	1991
K137784 - K138260	1992
SERIES "SK"	
SK101 - SK4350	1964 - 1967
SK4351 - SK13820	1968 - 1971
SK13821 - SK26835	1972 - 1975
SK26836 - SK36612	1976 - 1979
SK36613 - SK43412	1980 - 1985
SK44482 - SK45121	1986
SK45122 - SK46566	1987
SK46567 - SK48371	1988
SK48372 - SK50328	1989
SK50329 - SK52542	1990

SK52543 - SK53674	1991
SK53675 - SK54099	1992
SERIES "A"	
A101 - A3190	1964 - 1967
A3191 - A8115	1968 - 1971
A8116 - A19626	1972 - 1975
A19627 - A33453	1976 - 1979
A33454 - A45936	1980 - 1985
A47586 - A49686	1986
A49686 - A52777	1987
A52778 - A55603	1988
A55604 - A57841	1989
A57842 - A60425	1990
A60426 - A61781	1991
A61782 - A62070	1992
SERIES "KB"	
KB101 - KB550	1964 - 1967
KB551 - KB1309	1968 - 1971
KB1310 - KB1890	1972 - 1975
KB1891 - KB2465	1976 - 1979
KB2466 - KB2795	1980 - 1985
KB2835 - KB2862	1986
KB2863 - KB2982	1987
KB2983 - KB3052	1988
SERIES "KT"	
KT101 - KT4531	1964 - 1967
KT4532 - KT8506	1968 - 1971
KT8507 - KT12206	1972 - 1975
KT12207 - KT15895	1976 - 1979
KT15896	1980 - 1985
SERIES "F"	

F101 - F13850	1964 - 1967
F13851 - F22698	1968 - 1971
F22699 - F25630	1972 - 1975
F25631 - F26272	1976 - 1979
F26273 - F26828	1980 - 1985
F26828 - F26828	1986
SERIES "EC"	
EC101 - EC410	1968 - 1971
EC411 - EC1565	1972 - 1975
EC1566 - EC3638	1976 - 1979
EC3639 - EC6306	1980 - 1985
EC6826 - EC7212	1986
EC7213 - EC7792	1987
EC7793 - EC8465	1988
EC8466 - EC9124	1989
EC9125 - EC9605	1990
EC9606 - EC9932	1991
EC9933 - EC10044	1992
SERIES "SE"	
SE7624 - SE7827	1968 - 1971
SE7828 - SE12036	1972 - 1975
SE12037 - SE14784	1976 - 1979
SE14785	1980 - 1985
SERIES "KN"	
KN101 - KN440	1968 - 1971
KN441 - KN2173	1972 - 1975
KN2174 - KN3700	1976 - 1979
KN3701 - KN4330	1980 - 1985
KN4440 - KN4499	1986
KN4500 - KN4589	1987
KN4590 - KN4698	1988
KN4699 - KN4778	1989

KN4779 - KN4828	1990
KN4829 - KN4870	1991
KN4871 - KN4887	1992
SERIES "KH"	
KH101 - KH300	1968 - 1971
KH301 - KH1299	1972 - 1975
KH1300 - KH2485	1976 - 1979
KH2486 - KH3215	1980 - 1985
KH3265 - KH3314	1986
KH3315 - KH3454	1987
KH3455 - KH3527	1988
KH3528 - KH3587	1989
KH3588 - KH3618	1990
KH3618 - KH3629	1991
KH3630 - KH3653	1992
SERIES "BP"	
BP101 - BP146	1968 - 1971
BP147 - BP722	1972 - 1975
BP723 - BP1690	1976 - 1979
BP1691 - BP3053	1980 - 1985
BP3332 - BP3610	1986
BP3611 - BP3875	1987
BP3876 - BP4043	1988
BP4044 - BP4295	1989
BP4296 - BP4445	1990
BP4446 - BP4610	1991
SERIES "M"	
M101 - M2930	1972 - 1975
M2931 - M14400	1976 - 1979
SERIES "TP"	
TP101 - TP576	1976 - 1979

TP577 - TP888	1980 - 1985
SERIES "RA"	
RA101 - RA106	1980 - 1985
RA424 - RA924	1986
RA925 - RA1513	1987
RA1514 - RA2271	1988
RA2272 - RA2707	1989
RA2708 - RA3173	1990
RA3174 - RA4459	1991
RA3459 - RA3464	1992
SERIES "CF"	
CF101 - CF750	1980 - 1985
CF980 - CF1079	1986
CF1080 - CF1369	1987
CF1370 - CF1599	1988
CF1600 - CF1749	1989
CF1750 - CF1902	1990
CF1903 - CF1950	1991
CF1951 - CF1989	1992
SERIES "MB"	
MB101 - MB119	
SERIES "KTR"	
KTR200 - KTR303	1980 - 1985
SERIES "P"	
P101 - P314	1980 - 1985
P344 - P403	1986
P404 - P423	1987
P424 - P463	1988
P464 - P503	1989
P504 - P533	1990
P534 - P546	1991

P547 - P576	1992
NEW SERIAL NUMBERS STARTED "P" & "R"	
P00100 - P02064	1992
R00100 - R03428	1992

Last modified:
September 2010

Webmaster: Lars Kirmsen music_trader@musictrader.com
Copyright © 1995 - 2010 --- THE MUSIC TRADER

ALL RIGHTS RESERVED -- UNAUTHORIZED CACHING OR REPRODUCTION PROHIBITED BY LAW